

INTERFACE COMPONENTS

- AXDSPX-GL9 interface
- AXDSPX-GL9 interface harness
- AXDSPX-GL9 vehicle T-harness
 Bass knob

APPLICATIONS

Visit axxessinterfaces.com for current application list.

GM DSP Interface With Pre-Wired Harness

2014-2020

INTERFACE FEATURES

- Designed for non-amplifed models
- Includes a DSP (Digital Signal Processor)
- 31 Band graphic EQ or 5 Band Parametric EQ
- 10 individually assignable outputs
- Independent equalization on each of the 10 outputs
- Independent high pass, low pass, and bandpass filters
- Each channel can be delayed independently up to 10ms
- Clipping detection and limiting circuits
- Retains factory parking sensor chimes
- Retains OnStar® voice prompts
- · Adjustable chime level
- Easy behind the radio installation with pre-wired harness
- Bass knob included for level control of subwoofer amp
- Settings adjusted via Bluetooth® in a smart device application (tablet or mobile phone), compatible with both Android and Apple devices
- · Read, write, and store configurations for future recall
- Password protect feature available in the mobile app
- Micro-B USB updatable

TABLE OF CONTENTS

Installation Options	2
Installation	
Connections	3-4
Mobile App	
Specifications	

TOOLS & INSTALLATION ACCESSORIES REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink • Tape • Wire cutter
- Zip ties Multimeter

Google Play Store



Apple App Store



INSTALLATION OPTIONS

Adding a sub to a factory system:

This feature offers the ability to add a subwoofer to a factory system, whether amplified or nonamplified. (refer to page 3)

Adding a full-range amp & sub to a factory system:


This feature offers the ability to add a full-range amp and sub to a factory system, on a non-amplified system. (refer to page 4)

Note: The interface provides a 12-volt 1-amp output to turn on aftermarket amp(s). If installing multiple amps, an SPDT automotive relay will be required if the amp turn-on current of all amps combined exceeds 1-amp. Use Metra part number <u>E-123</u> (sold separately) for best results.


INSTALLATION

- **1.** Remove the factory radio †, then unplug all connectors.
- Install the AX-DSPX-GL9 vehicle T-harness to the vehicle and make all necessary connections, but leave the amp turn-on wire disconnected.
- 3. Plug the AX-DSPX-GL9 vehicle T-harness to the AX-DSPX-GL9 interface.
- Plug the AX-DSPX-GL9 interface harness to the AX-DSPX-GL9 interface.
- Download and install the AX-DSP-XL app from the Google Play Store or Apple App Store.
- **6.** Open the app then select the **Bluetooth Connection** tab. Follow the instructions to pair the mobile device to the interface. Refer to <u>page 6</u> for more information.
- Scroll to the Configuration tab then select the vehicle type. Press the Lock Down ‡ button to save the configuration. Refer to page 7 for more information.
- 8. Connect the amp turn-on wire.
- **9.** Adjust the settings in the app as desired. Press the **Lock Down** ‡ button to save any new configurations.
- Refer to <u>Metra online</u> for dash disassembly. If Metra makes a dash kit for the vehicle, disassembly will be within those instructions.
- ‡ Anytime the interface is locked down the key must be cycled off then back on.

ADDING A SUB TO A FACTORY SYSTEM




ADDING A FULL-RANGE AMP & SUB TO A FACTORY SYSTEM




MOBILE APP

Setup Instructions



• General information tab for installing the interface.

Bluetooth Connection




Scan - Press this button to start the Bluetooth pairing process, then select the interface
once it is found. "Connected" will appear in the top left corner of the app once paired.

Note: The ignition must be cycled on during this process.

• **Disconnect** - Disconnects the interface from the app.

Configuration




- **Identify** Click this button to send a test tone to the front left speaker*. * Only installations using the front left output (white RCA jack).
- **Reset to Defaults** Resets the interface to factory settings. During the reset process the amp(s) will shut off for 5-10 seconds.
- **Vehicle Type** Select the vehicle type from the drop down box, then click the apply button.
- Lock Down Click this button to save the selected settings. **Attention!** This must be done before closing the app or cycling the key otherwise all new changes will be lost!

- **Save Configuration** Saves the current configuration to the mobile device.
- Recall Configuration Recalls a configuration from the mobile device.
- **About** Displays information about the app, vehicle, interface, and mobile device.
- **Set Password** Assign a 4-digit password to lock the interface. If no password is desired, use "0000". This will clear out any currently set password. It is not necessary to lock down the interface when setting a password.

Note: A 4-digit only password must be chosen otherwise the interface will show "password not valid for this device".

Outputs



Output Channels


- **Location** Location of speaker.
- Group Used to join channels together for simple equalization. Example, left front woofer/midrange and left front tweeter will be considered simply left front. The letter M indicates the speaker assigned as the master speaker.
- **Invert** Will invert the phase of the speaker.
- Mute Will mute desired channel(s) for tuning individual channels.

Crossover Adjust




- If installing a subwoofer, the front and rear outputs will default to a 100Hz high pass filter to keep the low frequency signals out. If
 a subwoofer is not being installed, change the front and rear crossover points down to 20Hz for a full range signal, or to the lowest
 frequency the speakers will play down to.
- Selecting High Pass and Low Pass will provide one crossover frequency adjustment. Selecting Band Pass will provide two crossover frequency adjustments, one for low pass, and one for high pass.

Equalizer Adjust




- All channels can be adjusted independently within this tab with 31 bands of available equalization. It is best to tune this by using an RTA (Real Time Analyzer).
- The **Gain** slider on the far left is for the channel selected.

Delay Adjust




Allows a delay of each channel. If a delay is desired, first measure the
distance (in inches) from each speaker to the listening position, then
enter those values to the corresponding speaker. Add (in inches) to
the desired speaker to delay it.

Inputs/Levels



- **Chime Volume** Allows the chime volume to be adjusted up or down.
- Clipping Level Use this feature to protect sensitive speakers like tweeters from being driven past their capabilities. If the output signal of the interface clips the audio will be reduced by 20dB. Turning down the stereo will allow the audio to come back at a normal level. The sensitivity of this feature can be adjusted to the listening preference of the user.
- Amp Turn On
- Signal Sense Will turn the amp(s) on when an audio signal is detected, and keep on for 10 seconds after the last signal. This ensures the amp(s) won't shut off between tracks.
- Always On Will keep the amp(s) on as long as the ignition is cycled on.
- Turn on Delay Can be used to delay audio output to avoid turn-on pops.
- Subwoofer Input Select Front + Rear

Locking Down Data



Last and the most important:
You must lock down your
configuration and cycle the key!!!

SPECIFICATIONS

Input Impedance 1M Ohm Input Channels 6

Input Options High Level or Low Level Input Type Differential balanced

(high level range)

Input Voltage 0 - 4.9-volts (peak-to-peak)

(low level range)

Input Voltage

Ouput Channels 10

Output Voltage Up to 5-volts RMS

Output Impedance 50 Ohms

Equalizer Type 15 Band Graphic EQ or 5 Band

Parametric EQ, +/- 10dB

0 - 28-volts (peak-to-peak)

THD <0.03%

Frequency Response 20Hz - 20kHz

Crossover 3-Way LPF, BPF, HPF THP per channel

Crossover Type Linkwitz-Riley 24db slope

Sampling 48kHz

S/N Ratio 105dB @ 5-volts RMS

Operating Voltage 10-16 volts DC

Standby Current Draw 7mA
Operation Current Draw 150mA

Adjustments/Controls Application via Bluetooth
Remote Output 12 volts DC (signal sense

or with ignition



Having difficulties? We're here to help.



Contact our Tech Support line at: **386–257–1187**



Or via email at: techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 7:00 PM Sunday: 10:00 AM - 4:00 PM



KNOWLEDGE IS POWER Enhance your installation and fabrication skills by

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.edu or call 386-672-5771 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians