



70-1785
INSTALLATION INSTRUCTIONS

**Amplified / Bose
Integration Harness**

1988-95 Audi/Volkswagon

NOTE:

For **Audi** vehicles, be sure to insert the Blue/White wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, the Blue/White wire also supplies the signal to turn on the antenna.

For **Volkswagen** vehicles, be sure to insert the Blue/White wire (supplied) into pin 3 on the 16-way harness, right next to the Red accessory wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, insert the Blue wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's antenna turn-on wire.



70-1785
INSTALLATION INSTRUCTIONS

**Amplified / Bose
Integration Harness**

1988-95 Audi/Volkswagon

NOTE:

For **Audi** vehicles, be sure to insert the Blue/White wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, the Blue/White wire also supplies the signal to turn on the antenna.

For **Volkswagen** vehicles, be sure to insert the Blue/White wire (supplied) into pin 3 on the 16-way harness, right next to the Red accessory wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, insert the Blue wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's antenna turn-on wire.



70-1785
INSTALLATION INSTRUCTIONS

**Amplified / Bose
Integration Harness**

1988-95 Audi/Volkswagon

NOTE:

For **Audi** vehicles, be sure to insert the Blue/White wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, the Blue/White wire also supplies the signal to turn on the antenna.

For **Volkswagen** vehicles, be sure to insert the Blue/White wire (supplied) into pin 3 on the 16-way harness, right next to the Red accessory wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, insert the Blue wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's antenna turn-on wire.



70-1785
INSTALLATION INSTRUCTIONS

**Amplified / Bose
Integration Harness**

1988-95 Audi/Volkswagon

NOTE:

For **Audi** vehicles, be sure to insert the Blue/White wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, the Blue/White wire also supplies the signal to turn on the antenna.

For **Volkswagen** vehicles, be sure to insert the Blue/White wire (supplied) into pin 3 on the 16-way harness, right next to the Red accessory wire, and connect it to the aftermarket radio's amplifier turn-on wire. For models with power/amplified antennas, insert the Blue wire (supplied) into pin 5 of the 16-way harness, right next to the Orange/White wire, and connect it to the aftermarket radio's antenna turn-on wire.

