

# **Honda Element 2003-2011 Amp integration harness**

## **Connections to be made**

From the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire the battery wire.
- Connect the **Red** wire the accessory wire.
- Connect the **Orange** wire to the illumination wire. If the aftermarket radio has no illumination wire, tape off and disregard the **Orange** wire.
- Connect the **Blue/White** wire to the amp turn on wire. This wire must be connected

*(Continued on other side)*

**1-800-253-TECH**  
**[www.metraonline.com](http://www.metraonline.com)**

to hear sound from the factory amplifier.

- Connect the **White** RCA jack to the left front RCA output.
- Connect the **Gray** RCA jack to the right front RCA output.
- Connect the **Green** RCA jack to the left rear RCA output.
- Connect the **Purple** RCA jack to the right rear RCA output.
- Connect the single **Red** RCA jack to the subwoofer RCA output.

To retain AUX control:

- Connect the **White** RCA jack to the left AUX input.
- Connect the **Red** RCA jack to the right AUX input.

**1-800-253-TECH**  
**[www.metraonline.com](http://www.metraonline.com)**