

#### 19+ H-D GTS CarPlay/Android Auto activation plug



#### ***This installation is inside front Fairing.***

*For instructions on how to remove fairing, please reference [metraonline.com](http://metraonline.com). Search [BC-HDR-K1](#).*

1. Using a pry tool pop off the support holding the OE plug into place. (Fig: A)
2. With fairing removed, disconnect the OEM plug from harness or dust cover. (Fig: B)



Fig: A



Fig: B

3. Connect the BC-9728 to the OEM harness, and reinstall harness support to inner fairing.  
**NOTE: Will not work with H-D WHIM (Wireless Headset Interface Module) systems.**
4. Complete install by connecting phone to USB, and allowing the connection on the mobile device.

