

Installation instructions for Saddle Tramp's selectable brake light strobe kit. Select the pattern for your Incandescent or LED brake light. Maximum current rating 7A, 12vdc, at 84 watts.

**Step 1:** Remove seat and find brake light harness. See images below for reference.

**Step 2:** Find the rear taillight plug located under the seat, for 10-13 models the location may be behind the side panel in front of the saddle bag, belt side.

**Step 3:** Unplug the OE connector and plug in the BC-HDSSFx t-harness.

**Step 4:** Using the rotary switch on the control box find the preferred pattern.

**Step 5:** Secure the wiring harness and control box and reassemble.

Applications: Refer to the Saddle Tramp Website for full application information.

2014-Up BC-HDSSF1 Touring Models – Street Glide, Road Glide, Road King

1996-2013 BC-HDSSF2 Touring Models – Electra Glide, Ultra Classic/Limited, Road King & Classic, Road Glide Standard/Ultra/Custom

2010-2013 BC-HDSSF3 Touring Models – Street Glide and Road Glide.

- Pattern 0: 4 slow flashes then solid (Incandescent or LED)
- Pattern 1: 4 slow flashes, solid for 3 Seconds, Repeat (Incandescent or LED)
- Pattern 2: 7 slow flashes then solid (Incandescent or LED)
- Pattern 3: 7 slow flashes, solid for 3 seconds, repeat (Incandescent or LED)
- Pattern 4: 4 strobes, solid for 1 second, 4 strobe (LED Only)
- Pattern 5: 4 Strokes, solid for 1 second, 4 strobe, solid for 3 seconds, repeat (LED Only)
- Pattern 6: Constant strobe 4 seconds, then solid (LED Only)
- Pattern 7: Constant strobe, repeat (LED Only)
- Pattern 8: Fast strobe 6 seconds, solid (LED Only)
- Pattern 9: Fast constant strobe (LED Only)

