

1. Unscrew the (4) plastic screws securing the OE air dam to the bottom of the front bumper, remove screws and inserts (Figure A)
2. Remove the remaining (2) plastic screws securing the air dam to the lower cross member. (Figure B)
3. Locate the wiring harness plug, lift up the clip and pull connector off of fog light. (Figure C)
4. Remove the (4) screws securing each fog light to the bumper and remove the fog lights. (Figure D)
5. For 2010-2018 Wrangler plug JPJWFLAH (not included) into factory harness.
6. To install, repeat steps in reverse order.



Figure A



Figure B



Figure C



Figure D

- Using pry tool lift insert from center of clip, remove the (8) inserts and clips from lower air dam. (Figure A)
- Remove the (2) 8mm retainer bolts from the lower air dam. (Figure A)
- Remove splash guard/bumper cover
 - Sport** - splash guard. (Figure B) Remove (1) 8mm bolt, and (6) T-25 Torx® screws from bumper splash guards. (Figure C)
 - Rubicon / Sierra** - bumper cover. Using pry tool to remove 6 panel clips.
- Removing the fog lights
 - Rubicon** - Remove (4) 8mm screws holding light in, and disconnecting harness. (Figure D)
 - Sport** - Remove (3) T-25 Torx® screws holding fog light bracket on. (Figure E)
- Wrangler plug JPJWFLAH (not included) into factory harness.
- To install, repeat steps in reverse order.



Figure A



Figure B



Figure C



Figure D



Figure E