



HE-GMBK11

22" Hidden Light Bar Mount

2007-2013 Chevy 1500

Installation:

1. Start by removing the three 10mm bolts from behind the bumper opening.
2. Remove the push pins that are holding the rubber air flap in place and place aside for later.
3. Push down on flap and move it out of your way until needed.
4. Install light bar onto bracket ***before*** placing bracket with light bar into the opening of the bumper.

NOTE: Do not fully tighten down the bolts that are used to attach light bar to the bracket.

5. Place light bar and bracket combo into the opening of the bumper from the rear, moving rubber flap aside if needed.
6. Once light bar and bracket combo are in place, take the three previously removed 10mm factory bolts and

thread them through the bracket and into their factory bumper mounting locations.

NOTE: Do not fully tighten down the three 10mm bolts until centering of the light bar combo has been made.

7. Replace rubber flap to its original state and secure it back in place with the previously removed push pins.
8. Adjust light bar to achieve the desired angle and fully tighten down the light bar bolts.
9. Run power wires to their appropriate locations; avoid pinch points and other areas where wires may get severed or damaged.



386-257-2956

www.HeiseLED.com

460 Walker Street, Holly Hill, FL 32117