



22" HEISE Hood Bracket Installation

Jeep JK 2007-2018

Excludes: JK 2013 and up "Special Editions" with raised hood as well as JL models

Brackets will accommodate a 22" Straight Light bar

Tools needed: T50 Torx bit, 3/8" ratchet, 5mm Allen key, a second person (highly recommend), penetrating liquid (might be needed depending on vehicle).

1. Start by removing the (2) T50 Torx bolts from either the driver or passenger side of the vehicle's hood.



2. Now remove the adhesive backing on the rubber gasket and stick it to the bottom of the HEISE Hood bracket.
NOTE: Align gasket to holes on bracket, also apply rubber gasket to a clean surface.
3. Place bracket with gasket on hood and replace the Torx bolts with the new 8mm x 40mm long Button head

Allen bolt, be sure to also use the supplied nylon washers. Use a 5mm Allen key (making sure not to tighten down completely until all bolts are threaded, this will insure proper fitment).



4. Repeat these steps for the other side.
5. **NOTE:** this step will require two people. After both HEISE brackets are in place, you and your helper will align the 22" LED light bar between the HEISE brackets.
6. Once light is in place insert Allen head bolt (supplied with HEISE LED light bar) through bracket into the light bar securing it (with supplied Allen key, also with HEISE LED light bar) at the desired angle.



1-800-221-0932

www.HeiseLED.com

460 Walker Street, Holly Hill, FL 32117

08/01/2018