



Replacement Smoked Side Markers for JEEP WRANGLERS

HE-JWSSM

(Smoked Side Markers)

Applications: 2007-Current Jeep Wranglers

Tools Needed – Flat Head Screwdriver

Instructions:

1. Remove the two push pins on the side of the fender near the side marker light.
2. Unplug the original side marker light and remove the OEM bulb.
3. To remove side marker light, pull the fender out towards you while at the same time pushing down on the clip located on the top of the light.
4. Remove the original side marker light.

5. Insert the new **HEISE** LED side marker light by putting the bottom hooks in before snapping the top clip into place.
6. Plug OEM harness into the new light.
7. Align the fender back and reinsert the two push pins previously removed to secure the fender back in place.

Specifications:

(8) 2835 LEDs for a total of 4 watts
LED color: 2000K
DOT approved for on-road use
Plugs into OEM Harness
Dust/Water resistance: IP67



1-800-221-0932

www.HeiseLED.com

460 Walker Street, Holly Hill, FL 32117