



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



70-1719
INSTALLATION INSTRUCTIONS

2003-2011
Honda Element
Amp Bypass Harness

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13



Factory Amp Locations:

Passenger Side Kick Panel

Wire Colors for Bypass Harness:

Green/White	Sub Coil 1 (+)
White/Red	Sub Coil 1 (-)
Brown/Yellow	Sub Coil 2 (+)
Brown/Blue	Sub Coil 2 (-)

The rest of the wire colors are standard EIA/Metra color code that can be found on the back of this package.

Note:
Honda uses a dual voice coil subwoofer that needs to be crossed over to avoid damage to it.

REV. 8/2/13