



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



70-5701 INSTALLATION INSTRUCTIONS

Ford

1998-2001 Crown Victoria
 2001-03 Escape
 1998-2003 Explorer
 2001-03 Explorer Sport Trac
 1999-2003 Expedition (Early 2003
 Production Models)
 2001-03 Mustang with Mach 460 or
 Mach 1000 Sound systems
 2002-03 Ford Thunderbird
 2004-05 Ranger

Lincoln

2003 Aviator
 1998-2003 Continental
 2000-03 LS
 1999-2003 Navigator
 1998-2001 Town Car

Mercury

1998-2003 Grand Marquis
 1998-2003 Mountaineer



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION



REV 12/30/05
INST70-5701

Instructions:

Wire up the 70-5701 per the EIA/Metra color code that can be found on the back of the package. Most of the applications above will only use the WHITE RCA; the RED RCA will not be used.

Only the 2001-03 Ford Mustang, 2002-03 Ford Thunderbird and the 2000-03 Lincoln LS will use BOTH WHITE and RED RCA's.

1-800-221-0932 www.metraonline.com
© COPYRIGHT 2004 METRA ELECTRONICS CORPORATION