

ASWC-1

Axxess Steering Wheel Control Interface

www.axnessinterfaces.com

BEFORE YOU BEGIN

From the Axxess website, www.axnessinterfaces.com, click on the link titled "VEHICLE FIT GUIDE AND ASWC-1 INSTRUCTIONS", which is located on the top set of tabs. Once you have input your vehicle information, click on the "SUBMIT" button. This will take you to a page where you will be notified if your vehicle will work or not with the interface. If the interface is compatible, there will be a link under the green bar titled "ASWC-1 Installation Instructions". Click on this link to open the PDF document for your specific vehicle. Print this document so you will have it with you in the vehicle during the install.

INTERFACE COMPONENTS

- ASWC-1 Interface • 12-pin harness with male 3.5mm connector
- Female 3.5mm connector with Brown and Brown/White wires
- 12k-ohm resistor (needed with certain Kenwood Radios)

Note: Though we have done extensive research, testing, and verifying that the steering wheel control wires of the vehicles listed are correct. It is still the installers responsibility to verify that the steering wheel control wires are truly correct. If a discrepancy is found, please notify our Tech Department at 1-800-253-TECH, or techsupport@metra-autosound.com.

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

ASWC-1

Interfaz de control en volante Axxess

www.axnessinterfaces.com

ANTES DE EMPEZAR

Desde el sitio web de Axxess, www.axnessinterfaces.com, y haga clic en el enlace titulado "VEHICLE FIT GUIDE AND ASWC-1 INSTRUCTIONS" (guía de ajuste del vehículo e instrucciones de ASWC-1), que está en el conjunto superior de pestañas. Una vez que haya ingresado la información de su vehículo, haga clic en el botón "SUBMIT" (enviar). Esto lo llevará a una página en la que se le notificará si su vehículo va a funcionar o no con la interfaz. Si la interfaz es compatible, habrá un enlace debajo de la barra verde titulado "Instrucciones ASWC-1 de instalación". Haga clic en este vínculo para abrir el documento PDF para su vehículo específico. Imprima este documento para que lo tenga con usted en el vehículo durante la instalación.

COMPONENTES DE LA INTERFASE

- Interfase ASWC-1 • Arnés de 12-pins con conector macho de 3.5mm
- Conector hembra de 3.5mm con los cables marrón y marrón/blanco
- Resistencia de 12k-ohmios (necesaria con ciertos radios Kenwood)

Nota: Aunque hemos llevado a cabo pruebas e investigación extensas y verificado que los cables del control en el volante de los vehículos que enumeramos sean correctos, sigue siendo responsabilidad suya verificar los cables del control en el volante son realmente correcta. Si encuentra alguna discrepancia, por favor notifique a nuestro Departamento Técnico al 1-800-253-TECH, o techsupport@metra-autosound.com.

¡PRECAUCIÓN! Todos los accesorios, interruptores, paneles de controles de clima y especialmente las luces del indicador de las bolsas de aire deben estar conectados antes ciclar la Ignición. Además, no quite el radio de fábrica con la llave en la posición o de encendido ni con el vehículo funcionando.