

## Ford (w/ 4.2-inch screen) 2014-Up

Visit [AxxessInterfaces.com](http://AxxessInterfaces.com) for more detailed information about the product and up-to-date vehicle specific applications

### FEATURES

- “Plug & Play” supplemental harness for the AXAC-FD1 harness and AXAC-1 interface (both sold separately) to provide a turn signal trigger in 4.2-inch display screen models.

### TOOLS REQUIRED

- Panel removal tool • 9/32” Socket wrench

### INSTALLATION

The AXAC-FDSTK will connect at the turn signal indicator in the steering column. There are two different harnesses that Ford uses with different models. Use the harness that connects to the turn signal indicator and discard the other.

1. Remove (2) 9/32” screws underneath the steering column shroud.
2. Place the steering column in the downward position. Turn the steering wheel slightly to the right to access the front of the shroud. Using a panel tool, pry and release the right side of the shroud. Once complete, do the same for the opposite side.
3. Slide the shroud slightly forward, then remove.
4. Unplug the turn signal indicator harness, then insert the AXAC-FDSTK harness in between. (Figure A)
5. Route the (2) bare wires to the AXAC-FD1 harness.



(Figure A)

### CONNECTIONS

- From the **AXAC-FDSTK** harness to the **AXAC-FD1** harness, connect together the following wires:
  - **Blue/Black to Blue/Black**
  - **Blue/Red to Blue/Red**