

## Installing Ferrules on OGA wire

---



---

T-Spec OGA wire has a very tight fit with standard ferrules, which helps create a secure and durable connection. Following these steps will make finishing the cable with ferrules easier.

- 1) Cut wire to length
- 2) Strip back 0.75" of insulation
- 3) Chamfer edge of insulation with knife to allow for easier insertion
- 4) Insert wire into ferrule and crimp using a ferrule crimping tool