

99-7620B Tech Tip

The vehicle side harness¹ you use with this kit has a long black wire with a ring terminal on it.

This wire needs to be connected to chassis ground **before** you connect the interface to power. Failure to do so may cause damage to the interface.

If your vehicle side harness¹ does not have this wire, please add one before connecting the interface.

Note: Do not connect this wire to the radio ground, vehicles that use this kit may not have a ground in the factory wiring harness. It is recommended that you use a self-tapping screw to bare clean metal in the vehicle. Always check for clearance before drilling holes or screws.

¹The vehicle side harness used in this kit will be either "LD-7620-MAIN" or "LD-7620-NAV"