



## Hazards remain flashing fix

- Locate the 12pin connector from the LD-8163.(Figure A)
- Cut and tape off the Green/Orange wire (Figure B)



(Figure A)



(Figure B)