




# DAYTONA LIGHTS™

## DL-RGBK3




- A: Activate music function
- B: Power
- C: Activate color mode and Changes color
- D: Patterns

Single color Selection

4 Color Changing Modes

After thoroughly cleaning mounting surface, remove the protective tape and stick the LED strip to the mounting surface.



### Connections

\*Use cigarette adapter or loose wires

Loose Wires: Red - 12V+  
Black - Chassis Ground  
Blue - Brake Trigger

### Brake Trigger:

Connect the blue wire to the 12V+ brake light wire. When the brake light is activated, the LEDs will switch to red. LEDs will return to previous state once the brake is released.