

The **AXDSPL-BT** will be used for adding a Bluetooth interface to the **AXDSP-L** for playing music files directly to the interface.

- While playing music the volume on the phone will be used. As an option, the **AXBK-1** (sold separately) can be used to control the volume.

**Note:** The **AXBK-1** included with the **AXDSP-L** can also be used if it will not be used to control a subwoofer.

1. **Important!** Unplug the **AXDSP-L** from the vehicle.
2. Remove (4) Phillips screws securing the **AXDSP-L** interface, then remove the top cover, exposing the circuit board within.
3. Locate the 16-pin header on the circuit board.
4. **Important!** Referencing how the Bluetooth interface is laid out in the picture, carefully line up the header pins to the **AXDSPL-BT** Bluetooth interface. Gently press down to secure.

**Note:** Both interfaces may be damaged if installed wrong.

5. Reinstall the top cover to complete the installation.

#### **AXBK-1 installation:**

6. Connect the **Brown** wire from the **AXDSP-L** to the **Orange** wire from the **AXBK-1**. Ground the **Black** wire from the **AXBK-1**.

