

H-D Touring, Battery power T-Harness



This installation is under the seat, in front of the Battery.

For instructions on how to remove seat, please reference vehicles owner manual.

1. With seat removed, locate the factory battery output harness.
2. If there is a harness connected, remove and connect the mating ends of the BC-9719 to the OE plug(s).
3. Included are two battery power taps, both have heat shrink butt-connectors. To weather-proof the connections.

