



## BEFORE YOU BEGIN

1. Read these instructions and check to be sure all parts and tools are accounted for.
2. Please retain these installation instructions for future reference and parts ordering information

## IMPORTANT

1. This product fits Polaris RZR RPO.
2. Please read the installation instructions carefully before you start.
3. If the vehicle is clean and free of other debris, it will be easy to install.
4. For your safety and to ensure a satisfactory installation, please complete all the installation steps in the order shown below.

## INSTALLATION TIPS:

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove the three screws from the back of the original seat. Keep the spare.



3. Use the screws in step 2 to install the iron bracket (divided into left and right) in the corresponding position. Without tightening first, mount the Speaker stand on the iron bracket. Align the holes on the Speaker stand with the holes on the car body. Then remove the Speaker stand and tighten the iron bracket.



4. Use the screws in step 2 to fix the Speaker stand on the body, and then use 4x14 self-tapping screws to fix the Speaker stand on the iron bracket.



5. Installation is complete. Repeat step 2-4 on the other side.

