

THE INSTALLER'S CHOICE

A) Wrangler JK Installation

1. Remove the (6) six plastic fasteners at the top of the grille.

2. Gently lean grille forward to access panel clips at rear bottom of grille. Using a panel pry tool, release grille from clips.



3. Disconnect the left and right turning signal.



4. Remove the (4) four T-15 torx® screws that are holding the metal bracket ring around the headlights.



5. Remove and disconnect existing lights.



7. Optional connections:

Green wire: Turn signal (+12V)

Red wire: Day time running (+12V accessory power)

[Click Here for Diagram]

8. JK Wranglers 2007-2018 (JK) will use the H4 to H13 adapter included in kit.



9. Install lights into factory buckets, reusing the factory retaining ring. Please take note of orientation of the headlight, and tighten the four screws to secure the headlight.

10. Test light functionality and triggers. Alignment of the lights might be required, perform in accordance with the service manual.

11. Install front grille in reverse order of removal.

B) Wrangler JL/JT Installation

1. Remove the (6) six plastic fasteners at the top of the grille under the hood.

Starting at one side of the grille, firmly pull out on the bottom edge to release it from the panel.
 Continue this process across the entire lower edge until grille is free.



3. Remove (3) three, 10mm bolts from the OEM headlight assembly. Repeat on other side.



4. Install (<u>JP-JLB7</u>, sold separately) using factory 10mm bolts.
[Click here for installation instructions]



5. Optional connections: Green wire: Turn signal (+12V) Red wire: Day time running (+12V accessory power) [Click Here for Diagram]

- 6. Adjustments if needed can be found in the <u>JP-JLB7</u> instructions (sold separately).
- 7. Test light functionality and triggers.
- 8. Install front grille in reverse order of removal.



Rev:1 | Edit: 7/15/21