

2019-UP Wrangler JL | Radio Options W/Doors off

Radio stays playing with doors off, after turning off engine.

This is happening because the OE system has two available configurations. These settings can be found on page 230 of the vehicles owner's manual.

NOTE: When the doors have been removed, the key fob is used as the door event. Meaning you have to walk away from the vehicle, for the off-power delay to instate the timer.

| Setting Name | Description |
|---|---|
| Doors On Key Off Power Delay/Doors On Power Delay | This setting will keep certain electrical features running after the engine is turned on. When any door is opened, the electronics will deactivate. The available settings are "0 sec", "45 sec", "5 min", and "10 min". |
| Doors Off Key Off Power Delay/Doors Off Power Delay | This setting will keep certain electrical features running after the engine is turned off. When any door is opened, the electronics will deactivate. The available settings are "0 sec", "45 sec", "5 min", and "10 min". |

To change these settings, the OE screen must be used and vehicle needs to be in the ON/RUN position. Starting on page 219, press the uConnect Apps button, then press the Settings button on the touchscreen to display the menu setting screen. In this mode the Uconnect system allows you to access programmable features. When making a selection, only press one button at a time to enter the desired menu. Once in the desired menu, press and release the preferred setting option until a check mark appears next to the setting, showing that setting has been selected. Once the setting is complete, press the X button on the touchscreen to close out of the settings screen. Pressing the Up or Down Arrow button on the right side of the screen will allow you to toggle up or down through the available settings.

For more information see Jeep Owner's manual.

Official Jeep MOPAR.com PDF Owner's manual download site
<https://www.mopar.com/en-us/my-garage/select-vehicle.html>