



## **4.5” Replacement LED Auxiliary Lights for Motorcycles**

**HE-BAL451 (Black Front Face)**

**HE-SAL451 (Silver Front Face)**

### **Applications: Motorcycles with a 4.5” round Auxiliary Lights**

**Tools Needed** – Phillips Screwdriver

#### **Instructions:**

Refer to the motorcycle’s instructional manual for proper auxiliary light removal.

For most applications follow these steps:

1. Remove trim ring (if applicable) by removing (1) Phillips screw at bottom of trim ring.
2. Unplug the motorcycle’s harness from the auxiliary light and remove light.
3. Plug the harness into the new **HEISE** LED auxiliary light. There are some applications where the **HEISE** auxiliary

light needs to be hardwired. If that is the case then connect the **BROWN** wire of the **HEISE** auxiliary light to the (+) wire and the **BLUE** wire to the (-) wire of the motorcycles auxiliary lighting harness.

4. Install light and replace trim ring (if applicable).
5. Repeat previous steps for the other light.
6. Turn on auxiliary lights to ensure connections where properly made.

### **Specifications:**

(6) 5 watt CREE LEDs  
1260LM, draws 1.3a @ 13.8v  
DOT approved for on-road use  
LED color temp: 6500K  
Polycarbonate lens  
9145 connector with pigtail



**1-800-221-0932**

**[www.HeiseLED.com](http://www.HeiseLED.com)**

**460 Walker Street, Holly Hill, FL 32117**