

## **Installation Instructions**

These steps apply to the IBNF5, IBNF10, IBNF30, IBNF40 and IBNF50.

Red - 12v Input (This is the power source)

**Blue** -12v Output (This is the device you are filtering)

Black - Ground

