


Universal Camera *InstallBay*[®]

INSTALLATION HARDWARE



Harness Loops

- **Green loop = Selectable parking lines**
- **White loop = Mirror Image (if available)**

Box Contents

- **Camera**
- **Extension wire**
- **Hardware**
- **Manual**

INSTALLATION INSTRUCTIONS

1. Mount the camera to the vehicle. Make sure there location is suitable for proper operation and visual of the surrounding areas. Make sure the area is void of emense heat and moving parts of the vehicle.
2. Find a proper location to run the wire into the vehicle.
3. The RED wire will need to be connected to a REVERSE trigger within the vehicle. Please verify this trigger with a digital multi-meter.
4. The BLACK wire will need to be connected to the Chassis ground of the vehicle.
5. The RED wire near the RCA can act as either a trigger from the other RED connection or can be used to power the camera. The two RED wires are connected together within the extension cable.
6. After running the extension cable to the monitor/aftermarket radio, connect the RCA into the proper connection, most commonly would be labeled as backup camera or reverse camera.