



## Porsche (with MOST\*25 amplifier) Data Interface 2004-2013

\* Media Oriented System Transport

### INTERFACE FEATURES

- Designed for MOST25 amplified systems
- Provides accessory power (12-volt)
- Provides NAV outputs (parking brake, reverse, and speed sense)
- Micro B USB updatable

### INTERFACE COMPONENTS

- AXDI-PO4 interface
- AXDI-PO4 harness

### APPLICATIONS

#### US Applications

<b>Porsche</b>	
911 (997).....	2004-2008
Boxster (987).....	2005-2009
Cayman (987).....	2005-2009

#### World Applications

<b>Porsche</b>	
911 (997).....	2004-2012
Boxster (987).....	2005-2012
Cayman (987).....	2005-2013

### TABLE OF CONTENTS

Connections: BLK-AXDI-PO4 Harness.....	2
Applicable Radios.....	3
Installation.....	3
Installing the Fiber Optic Cable.....	3
Tips.....	4

Visit [AxxessInterfaces.com](http://AxxessInterfaces.com) for more detailed information about the product and up-to-date vehicle specific applications

### TOOLS REQUIRED

- Wire cutter • Crimp tool • Solder gun • Tape
- Connectors (example: butt-connectors, bell caps, etc.)


**ATTENTION:** With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.

**NOTE:** Refer also to the instructions included with the aftermarket accessory before installing this device.

## CONNECTIONS: BLK-AXDI-PO4 HARNESS

### Installing the Fiber Optic Cable:

1. Remove the OE Fiber Optic Cable for the factory Radio



## APPLICABLE RADIOS

Without Steering Wheel Controls, with CDR24/PCM2.0/PCM2.1



## INSTALLATION

With the key in the off position:

- Connect the **AXDI-P04 harness** to the **AXDI-P04 interface**.
- Remove the dust cover from fiber optic port in the **AXDI-P04**.
- Connect the factory fiber optic cable into the **AXDI-P04**.
- Connect the **AXDI-P04 harness** to the **wiring harness** in the vehicle.

## INSTALLING THE FIBER OPTIC CABLE


### Installing the Fiber Optic Cable:

Removal of the original fiber optic connection is required to adapt to the **Media Oriented System Transport (MOST) interface**.


- Seat the **AXDI-P04** interface in the black connector housing provided with this kit and snap the housing in place. (Figure A)
- From the original **Fiber Optic Connector**: Using a pick tool, carefully pull this tab towards the outside edge for the connector housing. Gently remove the fiber optic insert from the connector. (Figure B)
- From the **MOST Interface**: Push the tab toward the dust cover and, using a needle nose plier, remove the dust cover. Replace the connector with the factory fiber optic cables in to the MOST interface's black connector housing. (Figure C)



(Figure A)



(Figure B)



(Figure C)




**TIP:**

By pressing MAIN and TRIP at the same time you can see how many MOST 25 components are connected in the fiber loop. This will give you an idea of how many AXFO-LOOP you will need for your install.



**TIP:**

In these types of vehicles there could be other MOST 25 modules that need to be bypassed in order for the audio to function correctly. It is recommended that you order AXFO-LOOP.



Having difficulties? We're here to help.



Contact our Tech Support line at:

**386-257-1187**



Or via email at:

[techsupport@metra-autosound.com](mailto:techsupport@metra-autosound.com)

**Tech Support Hours (Eastern Standard Time)**

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP  
certified technicians**