

Product information sheet

AXBUCH-MI Mitsubishi Backup Camera Retain/Add-On 2014-Up

INTERFACE FEATURES

- Retains the factory back-Up camera to an aftermarket radio
- Allows an aftermarket camera to be added to the factory screen

APPLICATIONS

MITSUBISHI			
Lancer	2014-Up	Outlander	2014-Up
Lancer Sportback	2014-Up	Outlander Sport	2014-Up

INTERFACE COMPONENTS

AXBUCH-MI harness

TOOLS REQUIRED

- Wire cutter
 Crimping tool
 Solder gun
 Tape
- Connectors (example: butt connectors, bell caps, etc.

Connections to be made

The AXBUCH-MI can be connected two different ways

To retain the factory back-Up camera to an aftermarket radio:

- Connect the (3) Black wires to chassis ground.
- · Connect the Red wire to accessory power.*
- If populated on the factory side, connect the **Green/Purple** wire to the reverse wire of the aftermarket radio. If not populated, a reverse wire for the radio will need to be sourced from the vehicle.
- Connect the male Yellow RCA jack to the rear camera input of the aftermarket radio.
- Tape off and disregard the following (1) wire, it will not be used in this application: Yellow.
 - * It is highly recommended to use the AXCSD-6V (sold separately) to provide the camera with the proper voltage.

To allow an aftermarket camera to be added to the OEM screen:

- Connect the (3) Black wires, and the aftermarket cameras ground wire, to chassis ground.
- · Connect the Yellow wire to battery power.
- Connect the power wire of the aftermarket camera to accessory power.
- Connect the female Yellow RCA jack to the aftermarket camera.
- Tape off and disregard the following (2) wires, they will not be used in this application: Green/Purple, Red.
 Note: If the Green/Purple wire is not populated on the factory side, a reverse wire will need to be sourced from the vehicle.