

# **AXDSP-L SPEC SHEET** INSTALLATION INSTRUCTIONS

## **Specifications**

Input Impedance Input Channels Input Options Input Type Input Voltage High Level Range Input Voltage Low Level Range

**Ouput Channels** Output Voltage **Output Impedance** Equalizer Type THD Frequency Response (rossover

Crossover Type Sampling S/N Ratio

1M 0hm Δ High-level or Low-level selectable Differential-Balanced

0 - 28-volts (peak-to-peak)

0 - 4.9-volts (peak-to-peak)

6 Up to 5-volts RMS 50 0hms 15 Band Graphic EQ, +/- 10dB < 0.03% 20Hz - 20kHz 2-Way low-pass (sub), high pass (front & rear) Linkwitz-Riley 24db slope, fixed 48kH7 105dB @ 5-volts RMS

# General

**Operating Voltage** Standby Current Draw Operation Current Draw Adjustments/Controls **Remote Output** 

Product Info

10-16-volts DC 7mA 150mA Application via Bluetooth 12-volts DC (signal sense or w/ ignition) Having difficulties? We're here to help.

Contact our Tech Support line at: 386-257-1187

Or via email at: techsupport@metra-autosound.com

## Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM Saturday: 10:00 AM - 7:00 PM Sunday: 10:00 AM - 4:00 PM



#### **KNOWLEDGE IS POWER**

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians

AxxessInterfaces.com