



## Mazda 5 (without NAV) 2006-2010


Visit [MetraOnline.com](http://MetraOnline.com) for more detailed information about the product and up-to-date vehicle specific applications

### KIT FEATURES

- DIN radio provision with pocket
- ISO DIN radio provision with pocket
- ISO DDIN radio provision
- Painted to match factory dash

### KIT COMPONENTS

- A) Radio housing • B) ISO DIN radio brackets • C) ISO DIN radio trim plate • D) ISO DDIN radio brackets • E) ISO DDIN radio trim plate • F) Pocket



### TABLE OF CONTENTS

Dash Disassembly .....	2-3
Kit Assembly	
–DIN radio provision with pocket .....	4
–ISO DIN radio provision with pocket .....	5
–ISO DDIN radio provision.....	6

### WIRING & ANTENNA CONNECTIONS (sold separately)

Wiring Harness: 70-7903

Steering Wheel Control Interface: ASWC-1

### TOOLS REQUIRED


- Cutting tool • Phillips screwdriver
- Panel removal tool

**Attention!** Let the vehicle sit with the key out of the ignition for a few minutes before removing the factory radio. When testing the aftermarket equipment, ensure that all factory equipment is connected before cycling the key to ignition.


## DASH DISASSEMBLY

1. Unclip and remove the shifter trim panel. (Figure A)
2. Remove (2) Phillips screws exposed below the shifter trim panel. (Figure B)
3. Unclip and remove the center console trim panels, then remove (1) Phillips screw per side. (Figure C, D)


*Continued on the next page*




(Figure A)



(Figure B)



(Figure C)




(Figure D)


## DASH DISASSEMBLY (CONT.)

4. Unclip and pull the center console towards the rear of the vehicle, then set aside. The console does not need to be removed. (Figure E)
5. Remove (2) screws securing the radio trim panel. (Figure F)
6. Unclip, unplug and remove the radio trim panel. (Figure G)


*Continue to Kit Assembly*



(Figure E)



(Figure F)




(Figure G)


## KIT ASSEMBLY

### DIN radio provision with pocket


1. Remove the metal DIN sleeve from the aftermarket radio
2. Slide the sleeve into the **radio housing** and secure by bending the metal locking tabs outward. (Figure A)
3. Slide the radio into the sleeve until it snaps into place. (Figure B)
4. Snap the **pocket** into the **radio housing**. (Figure C)
5. Locate the factory wiring harness and antenna connector in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Test the radio for proper operation.
6. Reassemble the dash in reverse order of disassembly to complete the installation.



(Figure A)



(Figure B)




(Figure C)


## KIT ASSEMBLY

### ISO DIN radio provision with pocket


1. Remove the metal DIN sleeve and trim ring from the aftermarket radio
2. Secure the **ISO DIN radio brackets** to the radio using screws supplied with the radio. (Figure A)
3. Slide the radio into the **radio housing** until it snaps into place. (Figure B)
4. Snap the **ISO DIN trim plate** onto the front of the **radio housing**. (Figure C)
5. Snap the **pocket** into the **radio housing**. (Figure D)
6. Locate the factory wiring harness and antenna connector in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Test the radio for proper operation.
7. Reassemble the dash in reverse order of disassembly to complete the installation.




(Figure A)



(Figure B)



(Figure C)




(Figure D)


## KIT ASSEMBLY

### ISO DDIN radio provision


1. Cut and remove the center bar from the **radio housing**. (Figure A)
2. Attach the **ISO DDIN radio brackets** to the inside edge of the **radio housing**. (Figure B)
3. Slide the radio into the bracket/radio housing assembly, then secure the using screws supplied with the radio. (Figure C)
4. Snap the **ISO DDIN trim plate** onto the front of the **radio housing**. (Figure C)
5. Locate the factory wiring harness and antenna connector in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Test the radio for proper operation.
6. Reassemble the dash in reverse order of disassembly to complete the installation.



(Figure A)



(Figure B)



(Figure C)





**99-7509**  
INSTALLATION INSTRUCTIONS



If you are having difficulties with the installation of this product, contact our Tech Support line either by phone at **386-257-1187**, or email at **techsupport@metra-autosound.com**. Before doing so, look over the instruction booklet a second time and ensure that the installation was performed exactly as the instruction booklet is stated. Have the vehicle apart and ready to perform troubleshooting steps before contacting Metra/Axxess Tech Support.



**KNOWLEDGE IS POWER**

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto [www.installerinstitute.com](http://www.installerinstitute.com) or call 800-354-6782 for more information and take steps toward a better tomorrow.



**Metra recommends MECP certified technicians**