



Honda **Wiring Harness 2006-2014**

HARNESS FEATURES

- Wiring harness for installation of an aftermarket radio
- Provides power and four speakers
- Retains balance and fade

APPLICATIONS

Honda							
Civic *	2009-2011	CR-V *	2010-2011	Fit	2007-2008	Odyssey	2008-2010
Civic	2006-2008	CR-V	2007-2009	Insight *	2010-2014		

* Without NAV

TABLE OF CONTENTS

Connections 2

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape • Wire cutter • Zip ties



CONNECTIONS

From the 70-1722 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- Connect the **Orange/White** wire to the illumination wire, if applicable.
- Connect the **Gray** wire to the right front positive speaker wire.
- Connect the **Gray/Black** wire to the right front negative speaker wire.
- Connect the **White** wire to the left front positive speaker wire.
- Connect the **White/Black** wire to the left front negative speaker wire.
- Connect the **Green** wire to the left rear positive speaker wire.
- Connect the **Green/Black** wire to the left rear negative speaker wire.
- Connect the **Purple** wire to the right rear positive speaker wire.
- Connect the **Purple/Black** to the right rear negative speaker wire.

For vehicles with a factory amplifier:

Models without factory NAV:

- **Civic 06-11:** Locate the 20-pin harness that was connected to the factory radio. Locate pin-16, a **Light Blue** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.
- **CR-V 07-11:** Locate the 20-pin harness that was connected to the factory radio. Locate pin-15, a **Red** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.
- **Odyssey 08-10:** Locate the 20-pin harness that was connected to the factory radio. Locate pin-16, a **Yellow/Green** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.

Models with factory NAV:

- **Civic 06-08:** Locate the 22-pin harness that was connected to the factory radio. Locate pin-20, a **Light Blue** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.
- **CR-V 07-09:** Locate the 20-pin harness that was connected to the factory radio. Locate pin-15, a **Red** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.
- **Odyssey 08-10:** Locate the 20-pin harness that was connected to the factory radio. Locate pin-16, a **Yellow/Green** wire, then connect that wire to the amp turn-on wire from the aftermarket radio.