



Polaris Slingshot Data Interface 2015-up*

*Visit AxxessInterfaces.com for up-to-date vehicle specific applications.

INTERFACE FEATURES

- Provides NAV outputs (parking brake, reverse, speed sense)
- Retains the factory USB
- Pre-wired ASWC-1 harness (ASWC-1 sold separately) *
- Retains balance and fade
- Micro “B” USB updatable

* For retention of Speed Dependent Volume Control only

INTERFACE COMPONENTS

- XSVI-9701-NAV interface
- XSVI-9701-NAV harness

TABLE OF CONTENTS

Connections to be made	2
Installing the XSVI-9701-NAV	3

TOOLS REQUIRED

- Wire cutter • Crimp tool • Solder gun • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

CONNECTIONS TO BE MADE

From the XSVI-9701-NAV harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Connect the **Green** wire to the left rear positive speaker output.
- Connect the **Green/Black** wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the **Purple/Black** wire to the right rear negative output.

The following (3) wires are only for a multimedia/navigation radio that requires these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Connect the USB jack to the aftermarket radio.

12-pin pre-wired ASWC-1 harness:

- This harness is to be used along with the optional ASWC-1 (sold separately) to retain Speed Dependent Volume Control only. If the ASWC-1 is not being used, disregard this harness. If it will be used, please refer to the ASWC-1 instructions for radio connections and programming.

Note: *Disregard the harness that comes with the ASWC-1.*

INSTALLING THE XSVI-9701-NAV

With the key in the off position:

- Connect the XSVI-9701-NAV harness into the interface, and then to the wiring harness in the vehicle.
- If installing an ASWC-1 (sold separately), connect it after you test the XSVI-9701-NAV, with the key in the off position.
- Turn the key to the accessory position and test all functions of the installation for proper operation, before reassembling the dash.



XSVI-9701-NAV

INSTALLATION INSTRUCTIONS



IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at 1-800-253-TECH. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians